

## INDIANAPOLIS S7S SR FO HRO ESD



Made from nubuck leather and lined on the inside with a special membrane, they are totally waterproof. With a fibreglass toe cap and a non-metallic anti-perforation insole, the shoe is lighter, more flexible and more thermoregulatory. The EVA and rubber sole, with SR HRO certification, guarantees excellent anti-slip performance and heat resistance, without compromising lightness and flexibility of movement. Anatomical and antistatic insole with transverse arch protection, distributing the loads exerted on the foot evenly, also helping to cushion the normal impacts of walking and preventing metatarsalgia. In addition, they are ESD, protecting against electrostatic discharges



EN ISO 20345:2022

- ✓ **100% waterproof**
- ✓ **100% non-metallic**
- ✓ **Lightness and flexibility of movement**
- ✓ **Insulation against cold and heat**
- ✓ **Heat-resistant sole up to 300°C**
- ✓ **Anatomical and antistatic insole with shock absorption in the heel and support for the transverse arch**
- ✓ **ESD (Electrostatic Discharge Safe)**

## TECHNICAL SPECIFICATIONS

<b>Exterior</b>	Nubuck leather
<b>Interior</b>	Mesh fabric and waterproof membrane
<b>Anti-perforation insole</b>	Non-metallic
<b>Insole</b>	Foam
<b>Toe cap</b>	Fiberglass
<b>Outsole</b>	Rubber and EVA
<b>Color</b>	Black – Brown - Camel
<b>Sizes</b>	36-47

## MAINTENANCE AND STORAGE CARE

You must follow these guidelines to allow that your footwear **keeps its quality and extend its durability**.

When taking off your shoes, let your footwear air out before storing them.

You should always keep your shoes dry and preferably clean. You can place a sheet of newspaper or absorbent paper inside the shoes to absorb the moisture from sweating. It prevents bad odors and the creation of bacteria that can cause fungus.

You must not use the same shoes twice in a row! The shoes must have time to completely dry the sweating that they have absorbed during the day. If they are damp, can develop bacteria causing unpleasant odors and, even more serious, the proliferation of fungus and consequently diseases, such as unwanted mycoses.

Clean regularly with a brush or cloth to prevent accumulation of dirt and preferably wash them at least once a month.

Regularly disinfect the shoe inside with a suitable spray, you can also use isopropyl alcohol or baking soda.

Wash the insole regularly and change it when it is not in its proper condition.

Shoes should be stored in their original packaging in a cool, dry place and away from light.

## CLEANING CARE

### HOW TO CLEAN TO REMOVE MORE DIFFICULT DIRT

**Leather footwear:** clean with a slightly damp cloth and, as the last option you can use a soft cloth or a soft brush with neutral soap. You should avoid this procedure as it can stain the leather, test before in a less visible area. Let it air dry, but not expose to the sun, after drying apply a moisturizing cream or shoe polish

**Suede footwear:** To protect against stains and water splashes, you should use a suitable waterproofing spray. Do not use water to clean this material. To clean, use a bristle brush and brush the shoes in the opposite direction to the suede fibers to remove dust and dirt. At the end, pass the brush in the suede fibers direction to leave it in the initial position.

**Microfiber and fabric footwear:** Microfiber can be washed or sanitized at up to 60°C without drying out or losing its original characteristics. You should only wash it with water and neutral detergent. Microfiber shoes should also dry at room temperature and in the shade, and never near sources of intense heat, such as clothes dryers, boilers, heaters, stoves, cookers or the sun, as the footwear can lose its flexibility.

**This sheet is for information purposes only and does not exempt you from consulting the manual that is supplied with the footwear.**

**Note:** The technical information provided, either verbally or in writing, is based on our current knowledge and should be considered as collaboration without commitment. The use of the product is beyond our control, thus, we rule out any responsibility for its improper use. The customer is responsible to confirm and validate (by testing) if the product is suitable for the process and the type of use in question. Our purpose is exclusively to guarantee the quality of the products, according to our standards.

## REFERÊNCIAS

SAP	Descrição	EAN
CHS01090336	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S3 HRO ESD #36	5604630195737
CHS01090337	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #37	5604630195744
CHS01090338	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #38	5604630195751
CHS01090339	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #39	5604630195768
CHS01090340	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #40	5604630195775
CHS01090341	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #41	5604630195782
CHS01090342	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #42	5604630195799
CHS01090343	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #43	5604630195805
CHS01090344	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #44	5604630195812
CHS01090345	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #45	5604630195829
CHS01090346	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #46	5604630195836
CHS01090347	INDIANAPOLIS SPORT SAFETY SHOE CAMEL NUBUCK S7S HRO ESD #47	5604630195843
CHS01090236	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S3 HRO ESD #36	5604630195614
CHS01090237	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #37	5604630195621
CHS01090238	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #38	5604630195638
CHS01090239	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #39	5604630195645
CHS01090240	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #40	5604630195652
CHS01090241	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #41	5604630195669
CHS01090242	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #42	5604630195676
CHS01090243	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #43	5604630195683
CHS01090244	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #44	5604630195690
CHS01090245	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #45	5604630195706
CHS01090246	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #46	5604630195713
CHS01090247	INDIANAPOLIS SPORT SAFETY SHOE BROWN NUBUCK S7S HRO ESD #47	5604630195720
CHS01090136	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S3 HRO ESD #36	5604630195492
CHS01090137	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #37	5604630195508
CHS01090138	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #38	5604630195515
CHS01090139	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #39	5604630195522
CHS01090140	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #40	5604630195539
CHS01090141	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #41	5604630195546
CHS01090142	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #42	5604630195553
CHS01090143	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #43	5604630195560
CHS01090144	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #44	5604630195577
CHS01090145	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #45	5604630195584
CHS01090146	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #46	5604630195591
CHS01090147	INDIANAPOLIS SPORT SAFETY SHOE BLACK NUBUCK S7S HRO ESD #47	5604630195607

**Note:** The technical information provided, either verbally or in writing, is based on our current knowledge and should be considered as collaboration without commitment. The use of the product is beyond our control, thus, we rule out any responsibility for its improper use. The customer is responsible to confirm and validate (by testing) if the product is suitable for the process and the type of use in question. Our purpose is exclusively to guarantee the quality of the products, according to our standards.